

# MONARCH

**Single Phase Induction Motors**  
**0.18 kW to 3 kW**



**TECO** 

**TECO Australia Pty. Ltd.**

# **MONARCH SINGLE PHASE INDUCTION MOTORS**

## **INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE**

### **1. HANDLING AND STORAGE**

Motors should be preferably stored in their normal operating positions. They should be stored in surroundings as clean and dry and free from vibration as possible.

If motors have been exposed to moisture during long periods of storage then the insulation resistance of the windings against the frame (earth) should be checked with the aid of a megger (max. d.c. voltage 500V) prior to installation.

If any motor damage is to be claimed as “warranty”, TECO Australia must be consulted prior to any work being carried out on motor.

### **2. INSTALLATION AND OPERATION**

Motors should be installed to the requirements of AS3000:2000 SAA Wiring Rules

The installation of the equipment shall be carried out in a manner that does not reduce the protection afforded by the equipment design.

When installing the motor the following points should be carefully checked:

- rated voltage and frequency
- ambient temperature should not exceed 40°C, unless confirmed with TECO sales office
- altitude does not exceed 1000 meters above sea level
- correct connection of motor (see below)

The use of the motor should conform to the specified degree of protection in accordance with AS1939.

Care must be taken to ensure that the cooling air can flow in and out unhindered. The space between the air intake and the nearest wall should be approximately equal to the shaft height of the motor. Foundations must be designed in such a way that vibration is avoided when the motor and the driven machine are running coupled.

Care should be taken to ensure that any condensate drain plugs are located at the lowest point of motor casing. Before mounting the transmission parts, the motor shaft should be cleaned with a solvent.

Secure motor to a level surface. Unevenness leads to mechanical deformation of the motor. The motor should be used only with coupling systems, which are elastic with respect to centre offset, angular displacement, longitudinal shift and torsional strain. Rigid coupling systems are not permissible (unless previously agreed).

If direct coupling is employed check centre offset and angular offset with screwed on test arm and dial gauge.

The following deviations should not be exceeded:

- Centre offset (radial measurement) 0.03 mm in 2 pole motors. 0.05 mm in motors with more than 2 poles. (the dial shows twice the value of the deviation).
- Angular offset (axial measurement) 0.10 mm.

Check alignment at normal operating temperature.

With applications involving belt transmission, unnecessary axial forces on the bearings can be avoided by positioning the shafts parallel to each other and keeping the pulleys perfectly aligned. The belt tension should be just sufficiently stretched to prevent slipping in service. If the pulleys are too small the motor shaft is likely to bend and this must be avoided.

### **2) CONNECTION DIAGRAMS**


This connection is indicated on the connection diagram inside terminal box lid and as shown on page3.

For special voltages and the like, different connections will be noted on the motor nameplate beside voltage.

All Motors are suitable for operation in both directions.

# MONARCH SINGLE PHASE INDUCTION MOTORS INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE

## CONNECTION DIAGRAMS



# MONARCH SINGLE PHASE INDUCTION MOTORS

## INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE

### 3. CLEANING, LUBRICATION AND MAINTENANCE

Periodical checking of the magnetic starter (where used) is recommended, in order to prevent serious problems developing such as oxidation and poor electrical contact.

The intake and outlet openings as well as the channels between the cooling fins must be kept clean and protected against clogging to prevent motor overheating.

Bearings are greased for life and need no further maintenance. This means that greasing can only be carried out during general overhauls when the motor is disassembled.

### 4. PROTECTION DEVICES

**Thermal Reset Overloads** are fitted to motors up to and including 1.1 kW. If overload should trip motor should be allowed to cool before the overload is reset. To reset the overload press the red button mounted on the motor terminal box. Supply to the motor should be disconnected before restart is attempted and cause for the overload should be investigated.

### 5. FAULT FINDING & RECOGNITION

Kind of Fault	Symptom	Cause	Remedy
Fail to Start without Load	Motionless And soundless	Power-off	Consult power company
		Switch-off	Switch-on
		No fuse	Install fuse
		Broken wires	Check wires and repair
		Broken lead	Check leads and repair
		Faulty winding	Check winding and repair
		Overload tripped	Reset overload
	Fuse blowing – (Circuit Breaker trips off, slow start with electromagnetic noise)	Short circuit	Check circuit
		Incorrect wiring	Check wiring
		Poor contact in circuit switches	Check and repair
		Broken wiring	Check and repair
		Poor contact of starting switch	Check and repair
		Incorrect connection of starting switch	Check and repair
Overload after start	Fuse blowing – Fail to restart due to circuit breaker tripping	Insufficient capacity of fuse or breaker	Replace fuse or breaker
		Overload	Lighten load
		High load at low voltage	Check circuit capacity and reduce load
		Faulty internal centrifugal switchgear	Send for repair
Overload after Start	Overheating of Motor	Overload or Intermittent Overload	Lighten Load
		Under-voltage	Check circuit capacity and power source
		Over-voltage	Check power source
		Fuse blowing (Single phase rotating)	Install the specified fuse
		Poor contact of circuit switches	Check and repair
		Poor contact of starting switch	Check and repair
	Speed falls sharply	Voltage drop	Check circuit and power source
		Sudden overload	Check machine

**MONARCH SINGLE PHASE INDUCTION MOTORS**  
**INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE**

Kind of Fault	Symptom	Cause	Remedy	
Overload after Start	Switch overheat	Insufficient capacity of switch	Replace switch	
		High load	Lighten load	
	Bearing Overheat	Misalignment between motor and load	Re-align	
		High bearing noise	Replace damaged bearing	
Motor does not start	Motors hums and / or does not accelerate	Load too great	Reduce load	
		Power supply is not sufficient	Increase power supply	
		Extension lead used	Decrease extension lead length	
			Increase current carrying capacity of extension lead	
Noise	Electro-magnetic noise induced by electricity	Occurrence from first operation	Check noise not normal	
		Sudden sharp noise and smoking	Short circuit of windings. Repair.	
	Bearing noise	Excessive noise	Replace the damaged bearing	
	Mechanical noise caused by machinery	Loose belt sheaf	Adjust key and lock the screw	
		Loose coupling	Adjust the position of couplings and tighten	
		Loose screw	Tighten screw	
		Fan rubbing	Adjust fan position	
	Mechanical noise caused by machinery	Rubbing as a result of ingress of foreign matter	Clean motor interior and ventilation ducts	
		Wind noise	Noise induced by air flowing through ventilation ducts	
		Induced by conveyance machine	Repair machine	
	Vibration	Electro-magnetic vibration	Short circuit of windings	Repair
			Open circuit of rotor	Repair
Vibration		Unbalanced rotor	Repair	
		Unbalanced fan	Repair	
Mechanical vibration		Broken fan blade	Replace fan	
		Un-symmetrical centres between belt sheaf	Align central points	
		Central points of couplings do not lie on the same level	Adjust the central points of couplings on the same level	
		Improper mounting installation	Lock the mounting screw	
	Motor mounting bed is not strong	Reinforce mounting bed		

## MONARCH SINGLE PHASE INDUCTION MOTORS INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE


### Performance Data 240 Volt, 50 Hz, Capacitor Start, Capacitor Run (ML series) 2 Pole – 3000 RPM

Rated Power (kW)	Frame Size	Current (Amps) $I_N$	Speed (RPM)	Efficiency (%)	Power Factor (p.u.)	Starting Torque $\frac{T_{st}}{T_N}$	Break-down Torque $\frac{T_b}{T_N}$	Starting Current $\frac{I_{st}}{I_N}$	Approx net Weight IM1001 Kg
0.37	71	2.5	2800	67	0.92	2.3	1.8	5.9	7
0.55	71	3.6	2800	70	0.92	2.5	1.8	5.4	8
0.75	80	4.7	2800	72	0.92	2.5	1.8	5.8	8.5
1.1	80	6.5	2800	75	0.95	2.5	1.8	5.7	9.5
1.5	90S	8.7	2800	76	0.95	2.5	1.8	5.8	12.5
2.2	90L	12.5	2800	77	0.95	2.5	1.8	5.8	14
3	100L	16.7	2800	79	0.95	2.5	1.7	6.0	20.5

### 4 Pole – 1500 RPM

Rated Power (kW)	Frame Size	Current (Amps) $I_N$	Speed (RPM)	Efficiency (%)	Power Factor (p.u.)	Starting Torque $\frac{T_{st}}{T_N}$	Break-down Torque $\frac{T_b}{I_N}$	Starting Current $\frac{I_{st}}{I_N}$	Approx net Weight IM1001 Kg
0.18	63	1.4	1400	60	0.92	2.3	1.7	5.9	5
0.37	71	2.6	1400	65	0.92	2.3	1.7	6.6	8.1
0.55	80	3.7	1400	68	0.92	2.5	1.7	5.3	8.9
0.75	80	4.8	1400	71	0.92	2.5	1.7	5.8	9.6
1.1	90S	6.6	1400	73	0.95	2.5	1.7	5.6	13
1.5	90L	8.8	1400	75	0.95	2.5	1.7	5.8	16
2.2	100L	12.8	1400	76	0.95	2.5	1.7	5.8	23
3	100L	17.1	1400	77	0.95	2.5	1.7	5.9	27

### Dimensions: Capacitor Start, Capacitor Run (ML series)



Frame Size	Mounting Dimensions (mm)																				Frame Dimensions (mm)					
											IMB14					IMB5										
	A	B	C	D	E	F	G	H	K	M	N	P	R	S	T	M	N	P	R	S	T	AB	AC	AD	HD	L
71	112	90	45	14	30	5	11	71	7	85	70	105	0	M6	2.5	130	110	160	0	10	3.5	145	145	125	210	255
80	125	100	50	19	40	6	15.5	80	10	100	80	120	0	M6	3.0	165	130	200	0	12	3.5	160	165	135	240	295
90S	140	100	56	24	50	8	20	90	10	115	95	140	0	M8	3.0	165	130	200	0	12	3.5	180	185	145	270	335
90L	140	125	56	24	50	8	20	90	10	115	95	140	0	M8	3.0	165	130	200	0	12	3.5	180	185	145	270	360
100L	160	140	63	28	60	8	24	100	12	-	-	-	-	-	-	215	180	250	0	15	4.0	205	215	170	280	380

**MONARCH SINGLE PHASE INDUCTION MOTORS**  
**INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE**

NOTES:


# MONARCH SINGLE PHASE INDUCTION MOTORS

## INSTRUCTIONS FOR HANDLING, INSTALLATION AND MAINTENANCE

### Performance Data 240 Volt, 50 Hz, Capacitor Start Run (MY series) 4 Pole – 1500 RPM

Rated Power (kW)	Frame Size	Current (Amps) $I_N$	Speed (RPM)	Efficiency (%)	Power Factor (p.u.)	Starting Torque $\frac{T_{st}}{T_N}$	Break-down Torque $\frac{T_b}{T_N}$	Starting Current $\frac{I_{st}}{I_N}$	Approx net Weight IM1001 Kg
0.37	71	2.7	1400	62	0.92	0.35	1.7	3.4	7
0.55	80	3.9	1400	64	0.92	0.35	1.7	3.5	9.5
0.75	80	5.0	1400	68	0.92	0.32	1.7	3.7	10
1.1	90S	6.8	1400	71	0.95	0.32	1.7	4.0	13
1.5	90L	9.0	1400	73	0.95	0.3	1.7	4.6	16

### Dimensions: Capacitor Start Run (MY series)



Frame Size	Mounting Dimensions (mm)																				Frame Dimensions (mm)					
											IMB14					IMB5										
	A	B	C	D	E	F	G	H	K	M	N	P	R	S	T	M	N	P	R	S	T	AB	AC	AD	HD	L
63	100	80	40	11	23	4	8.5	63	7	75	60	90	0	M5	2.5	115	95	140	0	10	3.0	130	130	115	185	230
71	112	90	45	14	30	5	11	71	7	85	70	105	0	M6	2.5	130	110	160	0	10	3.5	145	145	125	205	255
80	125	100	50	19	40	6	15.5	80	10	100	80	120	0	M6	3.0	165	130	200	0	12	3.5	160	165	135	235	295
90S	140	100	56	24	50	8	20	90	10	115	95	140	0	M8	3.0	165	130	200	0	12	3.5	180	185	145	265	335
90L	140	125	56	24	50	8	20	90	10	115	95	140	0	M8	3.0	165	130	200	0	12	3.5	180	185	145	265	360

### Bolt on feet – Multi-mount construction



**TECO Australia Pty. Ltd.**

www.teco.com.au      email: emd@teco.com.au

Sydney Head Office: 335-337 Woodpark Road, Smithfield, NSW 2164

Brisbane Office: 50 Murdoch Circuit, Acacia Ridge, QLD 4110

Melbourne Office: 16 Longstaff Road, Bayswater, VIC 3153

Perth Office: 28 Belgravia Street, Belmont, WA 6104

Tel: 02 - 9765 8118 Fax: 02 - 9604 9330

Tel: 07 - 3373 9600 Fax: 07 - 3373 9699

Tel: 03 - 9720 4411 Fax: 03 - 9720 5355

Tel: 08 - 9479 4879 Fax: 08 - 9478 3876

TECO New Zealand Pty. Ltd.: Unit 3, 477 Great South Road, Penrose, Auckland

Tel: 64 - 9 - 526 8480 Fax: 64 - 9 - 526 8484

